
X-Port Example set-up

This is how the set-up is displayed when viewed in TELNET:

MAC address 00204A937C97
Software version V6.1.0.2 (060217) XPTEXE

Press Enter for Setup Mode

*** basic parameters

Hardware: Ethernet TPI

IP addr 192.168.1.11, no gateway set, netmask 255.255.255.0

*** Security

SNMP is enabled

SNMP Community Name:

Telnet Setup is enabled

TFTP Download is enabled

Port 77FEh is enabled

Web Server is enabled

Web Setup is enabled

ECHO is disabled

Enhanced Password is disabled

Port 77F0h is enabled

*** Channel 1

Baudrate 19200, I/F Mode 4C, Flow 00

Port 08888

Connect Mode : C0

Send '+++ ' in Modem Mode enabled

Auto increment source port disabled

Remote IP Adr: --- none ---, Port 00000

Disconn Mode : 00

Flush Mode : F7

*** Expert

TCP Keepalive : 45s

ARP cache timeout: 600s

CPU performance: Regular

Monitor Mode @ bootup : enabled

RS485 tx enable : active low

HTTP Port Number : 80

SMTP Port Number : 25

MTU Size: 1400

Alternate MAC: disabled

Ethernet connection type: auto-negotiate

*** E-mail
Mail server: 0.0.0.0
Unit :
Domain :
Recipient 1:
Recipient 2:

- Trigger 1
Serial trigger input: disabled
Channel: 1
Match: 00,00
Trigger input1: X
Trigger input2: X
Trigger input3: X
Message :
Priority: L
Min. notification interval: 1 s
Re-notification interval : 0 s

- Trigger 2
Serial trigger input: disabled
Channel: 1
Match: 00,00
Trigger input1: X
Trigger input2: X
Trigger input3: X
Message :
Priority: L
Min. notification interval: 1 s
Re-notification interval : 0 s

- Trigger 3
Serial trigger input: disabled
Channel: 1
Match: 00,00
Trigger input1: X
Trigger input2: X
Trigger input3: X
Message :
Priority: L
Min. notification interval: 1 s
Re-notification interval : 0 s

Change Setup:
0 Server
1 Channel 1
3 E-mail
5 Expert
6 Security
7 Defaults
8 Exit without save
9 Save and exit Your choice ?

05/02/08